


Robustline rotary actuator for butterfly valves and rotary valves in Retrofit applications

- Torque 18 Nm
- · Nominal voltage AC 100 ... 240 V
- · Control: Open-close or 3-point

#### **Optimum protection against**

- · Corrosion and chemical influences
- UV radiation
- · Damp and condensation
- Low temperatures (for use in ambient temperatures up to -40°C, there is a separate actuator available with built-in heater ex works)



	·	
Technical data		
Electrical data	Nominal voltage	AC 100 240 V, 50/60 Hz
	Nominal voltage range	AC 85 265 V
	Power consumption In operation	2.5 W @ nominal torque
	At rest	0.4 W
	For wire sizing	6 VA
	Connection	Halogen-free cable 1 m, 3 x 0.75 mm <sup>2</sup>
	Parallel connection	Possible, note the performance data
Functional data	Torque (nominal torque)	Min. 18 Nm @ nominal voltage
	Manual override	Gearing latch disengaged with pushbutton, can be locked
	Running time	90 s / 90°⊲
	Sound power level	Max. 45 dB (A) (without butterfly valve resp. rotary valve)
	Position indication	Mechanical, pluggable
Safety	Protection class	II Totally insulated □
	Degree of protection	IP66 + IP67
	EMC	CE according to 2004/108/EC
	Low-voltage directive	CE according to 2006/95/EC
	Mode of operation	Type 1 (EN 60730-1)
	Rated impulse voltage	2.5 kV (EN 60730-1)
	Control pollution degree	4 (EN 60730-1)
	Ambient temperature	−30 +50°C
		(actuator with built-in heater –40 +50 °C)
	Non-operating temperature	–40 +50°C
	Ambient humidity	100% r.H.
	Maintenance	Maintenance-free
Dimensions / Weight	Dimensions	See «Dimensions» on page 4

#### Safety notes



Weight

 The actuator has been designed for use in stationary heating, ventilation and air conditioning systems and is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.

Approx. 1.55 kg

- · Caution: Power supply voltage!
- It may only be installed by suitably trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The switch for changing the direction of rotation may only be operated by authorised personnel. The direction of rotation must not be reversed in a frost protection circuit.
- The cover of the protective housing may be opened for adjustment and servicing. When it is closed afterwards, the housing must seal tight.
- The device on the inside may only be opened up in the factory. It does not contain any parts that can be replaced or repaired by the user.
- The cable must not be removed from the device.
- The device contains electrical and electronic components and is not allowed to be disposed
  of as household refuse. All locally valid regulations and requirements must be observed.

# Robustline rotary actuator, AC 100 ... 240 V, 18 Nm, for Retrofit applications



#### Safety notes

#### (continued)

- The information on chemical resistance refers to laboratory tests with raw materials and finished products and to trials in the field in the areas of application indicated.
- The materials used may be subjected to external influences (temperature, pressure, constructional fixture, effect of chemical substances etc.), that cannot be simulated in laboratory test or field trials.
- The information regarding areas of application and resistance can therefore only serve as a guideline. In case of doubt, we recommend that you definitely carry out a test. This information does not imply any legal entitlement. Belimo will not be held liable and will provide no warranty. The chemical or mechanical resistance of the materials used is not alone sufficient for judging the suitability of a product. Regulations pertaining to combustible liquids such as solvents etc. must be taken into account with special reference to explosion protection.

#### **Product features**

#### Fields of application

The actuator is particularly suited for use in difficult conditions, e.g. in the field of:

- Wood drying
- Animal breeding
- Food processing
- Agricultural
- Swimming baths / Bathrooms
- Rooftop units
- General outdoor applications
- Low temperatures (the separately available actuator with built-in heater ex works is suitable for use up to -40°C)
- Changing climate / frequent and strong fluctuations in temperature (Recommendation: to prevent internal condensation, use the separately available actuator with built-in heater ex works)

#### Resistances

Test	Test standard	Testing body	
Noxious gas tests	EN 60068-2-60	Fraunhofer Institute ICT / DE	
Salt fog spray test	EN 60068-2-52	Fraunhofer Institute ICT / DE	
Ammoniac test	DIN 50916-2	Fraunhofer Institute ICT / DE	
Climatic test	IEC 60068-2-30	Trikon Solutions AG / CH	
Disinfectants (animals)		Trikon Solutions AG / CH	
UV test	EN 60068-2-5	Quinel / Zug CH	
(Solar radiation at ground level)	EN 60068-2-63		

#### **Used materials**

Actuator parts	Material
Actuator housing	Polypropylene (PP)
Cable glands / hollow shaft	Polyamide ( PA )
Connection cable	FRNC
Clamp / screws in general	Steel 1.4404
Seals	EPDM
Form-fit insert	Anodised aluminium

#### Robustline rotary actuator, AC 100 ... 240 V, 18 Nm, for Retrofit applications



#### **Product features**

#### (continued)


#### **Application**


For butterfly valves and rotary valves (applications up to approx. DN80) with the following mechanical specifications:

- ISO 5211: F03, F04 or F05 (diameter of the circular hole on the flange for mounting the fitting)
- ISO 5211: square, flat head or cuneiform stem head geometry

Carrier shafts

ZPV-.. (square)





Type [mm] [mm] ZPF-08 8 10 ZPF-09 9 12 ZPF-10 10 14 ZPF-11 11 14 ZPF-14 14 18

ZSK-.. (cuneiform)



Туре	<b>d</b> <sub>7</sub> [mm]
ZPK-12	12
ZPK-14	14

#### Note

The carrier shaft ZPV-14 is supplied (additional see «Accessories»).

Simple direct mounting

Simple direct mounting on the butterfly valve or rotary actuator with mounting flange.

Manual override with push-button possible (the gear is disengaged for as long as the button is Manual override

pressed or remains locked).

\* only available fitted in separate actuator

Adjustable angle of rotation with mechanical end stops. Standard setting 0 ... 90° ◄. Adjustable angle of rotation

The housing cover must be removed to set the angle of rotation.

The actuator is overload-proof, requires no limit switches and automatically stops when the end High functional reliability

stop is reached.

#### **Accessories**

#### **Electrical accessories**

Mechanical accessories

Description	Data sheet
Auxiliary switch SA	T2 - SA
Feedback potentiometer PA	T2 - PA
Heating 230 V with thermostat HT230 *	T2 - HT230
Heating 230 V with humidistat HH230 *	T2 - HH230
Carrier shaft adapter ZPV-08 ZPV-14	
Carrier shaft adapter ZPF-08 ZPF-14	
Carrier shaft adapter ZPK-12, ZPK-14	

## **Electrical installation**


• Caution: Power supply voltage!


Direction of rotation Y2


Note performance data for supply. · Factory default direction of rotation switch:

Note

### Wiring diagrams







Open-close control

# N **Y2**

## 3-point control

Cable colours:

1 = blue2 = brown

3 = white

**Direction of rotation** 





Rotary actuator		Rotary valve
Y2	<b>→</b>	A - AB = 0%




## Dimensions [mm]








Flange	а	b
F03	Ø 36	4 x M5
F04	Ø 42	4 x M5
F05	Ø 50	4 v M6





#### **Further documentations**


- Complete overview «The complete range of water solutions»
  Data sheets, butterfly valves and rotary valves
- Installation instructions for actuators resp. butterfly valves and rotary valves
- Notes for project planning (hydraulic characteristic curves and circuits, installation regulations, commissioning, maintenance etc.)























AC 24 V / DC 24 V



SR24P-R


AC 100 ... 240 V



SR230P-R



AC 24 V / DC 24 V



SR24P-MP-R