

Parameterisable RobustLine damper actuator for adjusting dampers in industrial plants and in technical building installations

- Air damper size up to approx. 4 m<sup>2</sup>
- Nominal torque 20 Nm
- Nominal voltage AC/DC 24 V
- Control modulating DC (0)2...10 V Variable
- Position feedback DC 2...10 V Variable
- Optimum protection against corrosion and chemical influences, UV radiation, damp and condensation



	l data

Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 21.628.8 V
	Power consumption in operation	3.5 W
	Power consumption in rest position	1.3 W
	Power consumption for wire sizing	6 VA
	Connection supply / control	Cable 1 m, 4 x 0.75 mm <sup>2</sup> (halogen-free)
	Parallel operation	Yes (note the performance data)
Functional data	Torque motor	Min. 20 Nm
	Torque variable	25%, 50%, 75% reduced
	Positioning signal Y	DC 010 V
	Positioning signal Y note	Input impedance 100 kΩ
	Control signal Y variable	Open-close
		3-point (AC only)
	- <u>-</u>	Modulating (DC 032 V)
	Operating range Y	DC 210 V
	Operating range Y variable	Start point DC 0.530 V End point DC 2.532 V
	Position feedback U	DC 210 V
	Position feedback U note	Max. 0.5 mA
	Position feedback U variable	Start point DC 0.58 V
		End point DC 2.510 V
	Position accuracy	±5%
	Direction of motion motor	selectable with switch 0 / 1
	Direction of motion note	Y = 0 V: At switch position 0 (ccw rotation) / 1
	Direction of motion variable	(cw rotation)
	Manual override	electronically reversible with push-button, can be locked
	Angle of rotation	Max. 95°
	Angle of rotation note	can be limited on both sides with adjustable
	Angle of rotation note	mechanical end stops
	Running time motor	150 s / 90°
	Motor running time variable	86346 s
	Adaption setting range	manual
	Adaption setting range variable	No action
		Adaption when switched on
		Adaption after pushing the gear disengagement
		button
	Override control	MAX (maximum position) = 100%
	Overmide control veriable	MIN (minimum position) = 0%
	Override control variable	MAX = (MIN + 32%)100% MIN = 0%(MAX – 32%)
		ZS = MINMAX
	Sound power level motor	45 dB(A)
	Spindle driver	Universal spindle clamp 1420 mm
	Position indication	Mechanically, pluggable
Safety	Protection class IEC/EN	III Safety Extra-Low Voltage (SELV)
	Degree of protection IEC/EN	IP66 + IP67
	Degree of protection NEMA/UL	NEMA 4, UL Enclosure Type 4
		, , , , , , , , , , , , , , , , , , ,

# Damper actuator, IP66 + IP67, parameterisable, modulating, AC/DC 24 V, 20 Nm



## **Technical data**

#### Safety

EMC	CE according to 2014/30/EU	
Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14	
Certification UL	cULus according to UL 60730-1A, UL 60730-2- 14 and CAN/CSA E60730-1:02	
Mode of operation	Type 1	
Rated impulse voltage supply / control	0.8 kV	
Control pollution degree	4	
Ambient temperature	-3050°C	
Non-operating temperature	-4080°C	
Ambient humidity	100% r.h.	
Maintenance	Maintenance-free	
Weight	2.1 kg	

#### Safety notes



Weight

- The device must not be used outside the specified field of application, especially not in aircraft or in any other airborne means of transport.
- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- Junction boxes must at least correspond with enclosure IP degree of protection!
- The cover of the protective housing may be opened for adjustment and servicing.
   When it is closed afterwards, the housing must seal tight (see installation instructions).
- The device may only be opened in the manufacturer's factory. It does not contain any parts that can be replaced or repaired by the user.
- The cables must not be removed from the device installed in the interior.
- To calculate the torque required, the specifications supplied by the damper manufacturers concerning the cross-section, the design, the installation site and the ventilation conditions must be observed.
- The device contains electrical and electronic components and must not be disposed
  of as household refuse. All locally valid regulations and requirements must be
  observed.
- The information on chemical resistance refers to laboratory tests with raw materials and finished products and to trials in the field in the areas of application indicated.
- The materials used may be subjected to external influences (temperature, pressure, constructional fixture, effect of chemical substances, etc.), which cannot be simulated in laboratory tests or field trials.
- The information regarding areas of application and resistance can therefore only serve as a guideline. In case of doubt, we definitely recommend that you carry out a test. This information does not imply any legal entitlement. Belimo will not be held liable and will provide no warranty. The chemical or mechanical resistance of the materials used is not alone sufficient for judging the suitability of a product. Regulations pertaining to combustible liquids such as solvents etc. must be taken into account with special reference to explosion protection.

#### **Product features**

#### Fields of application

The actuator is particularly suitable for utilisation in outdoor applications and is protected against the following weather conditions:

- Wood drying
- Animal breeding
- Food processing
- Agricultural
- Swimming baths / bathrooms
- Rooftop ventilation plant rooms
- General outdoor applications
- Changing atmosphere
- Laboratories

# Damper actuator, IP66 + IP67, parameterisable, modulating, AC/DC 24 V, 20 Nm



#### **Product features**

Resistances Noxious gas test EN 60068-2-60 (Fraunhofer Institut ICT / DE)

Salt fog spray test EN 60068-2-52 (Fraunhofer Institut ICT / DE) Ammoniac test DIN 50916-2 (Fraunhofer Institut ICT / DE) Climate test IEC60068-2-30 (Trikon Solutions AG / CH)

Disinfectant (animals) (Trikon Solutions AG / CH)

UV Test (Solar radiation at ground level) EN 60068-2-5, EN 60068-2-63 (Quinel / Zug

CH)

Used materials Actuator housing polypropylene (PP)

Cable glands / hollow shaft polyamide (PA)

Connecting cable FRNC

Clamp / screws in general Steel 1.4404

Seals EPDM

Form fit insert aluminium anodised

Mode of operation The actuator is connected with a standard modulating signal of DC 0...10V and drives

to the position defined by the positioning signal. Measuring voltage U serves for the electrical display of the damper position 0...100% and as slave control signal for other

actuators.

Parameterisable actuators The factory settings cover the most common applications. Single parameters can be

modified with the Belimo Service Tools MFT-P or ZTH EU.

Simple direct mounting Simple direct mounting on the damper spindle with an universal spindle clamp,

supplied with an anti-rotation device to prevent the actuator from rotating.

Manual override Manual override with push-button possible (the gear is disengaged for as long as the

button is pressed or remains locked).

Adjustable angle of rotation Adjustable angle of rotation with mechanical end stops. Standard setting 0 ... 90°. The

housing cover must be removed to set the angle of rotation.


High functional reliability The actuator is overload protected, requires no limit switches and automatically stops

when the end stop is reached.

**Home position** The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out a synchronisation. The synchronisation is in the home position

(0%).

The actuator then moves into the position defined by the positioning signal.



#### Adaption and synchronisation

An adaption can be triggered manually by pressing the "Adaption" button or with the PC-Tool. Both mechanical end stops are detected during the adaption (entire setting range).

Automatic synchronisation after pressing the gearbox disengagement button is configured. The synchronisation is in the home position (0%).

The actuator then moves into the position defined by the positioning signal.

A range of settings can be adapted using the PC-Tool (see MFT-P documentation)

#### **Accessories**

#### **Electrical accessories**

Description	Туре
Auxiliary switch, add-on, 1 x SPDT	S1A
Auxiliary switch, add-on, 2 x SPDT	S2A
Feedback potentiometer 140 Ohm, add-on	P140A
Feedback potentiometer 140 Ohm, add-on, grey	P140A GR
Feedback potentiometer 200 Ohm, add-on	P200A
Feedback potentiometer 500 Ohm, add-on	P500A
Feedback potentiometer 500 Ohm, add-on, grey	P500A GR
Feedback potentiometer 1 kOhm, add-on	P1000A
Feedback potentiometer 1 kOhm, add-on, grey	P1000A GR
Feedback potentiometer 2.8 kOhm, add-on	P2800A
Feedback potentiometer 2.8 kOhm, add-on, grey	P2800A GR
Feedback potentiometer 5 kOhm, add-on	P5000A



## **Accessories**

	Description	
	Feedback potentiometer 5 kOhm, add-on, grey	
	Feedback potentiometer 10 kOhm, add-on	
	Feedback potentiometer 10 kOhm, add-on, grey	
	Signal converter voltage/current, supply AC/DC 24V	
	Digital position indicator for front-panel mounting, 099%, front mass $72 \times 72 \text{ mm}$	ZAD24
	Range controller for wall mounting, adjustable electron. Min./max. angle of rotation limitation	SBG24
Positioner for wall mounting, range 0100%		SGA24
	Positioner in a conduit box, range 0100%	
	Positioner for front-panel mounting, range 0100%	SGF24
	Positioner for wall mounting, range 0100%	CRP24-B1
	Connection cable 5 m, A+B: RJ12 6/6, To ZTH/ZIP-USB-MP	ZK1-GEN
	Connection cable 5 m, A: RJ11 6/4, B: Free wire end, To ZTH/ZIP-USB-MP	ZK2-GEN
	Description	Туре
Service Tools	Service tool for parametrisable and communicative Belimo actuators / VAV controller and HVAC performance devices	ZTH EU
	Belimo PC-Tool, software for adjustments and diagnostics	MFT-P
	Adapter to Service Tool ZTH	MFT-C

## **Electrical installation**




**Notes** 

- · Connection via safety isolating transformer.
- Parallel connection of other actuators possible. Observe the performance data.

## Wiring diagrams

AC/DC 24 V, modulating



## Cable colours:

1 = black

2 = red


3 = white

5 = orange


## **Functions**

## Functions with basic values (conventional mode)

Override control with AC 24 V with relay contacts




Override control with AC 24 V with rotary switch







## **Functions**


Minimum limit with positioner SG.. Remote control 0...100% with positioner SG..








Follow-up control (position-dependent)






Control with 4...20 mA via external resistor


Functional check

(1) Adapting the direction of rotation





DC 2...10 V. The 500  $\Omega$  resistor converts the 4...20 mA current signal to a voltage signal DC 2...10 V





## **Procedure**

- 1. Connect 24V to connections 1 and 2
- 2. Disconnect connection 3:
- with direction of rotation 0:
- Actuator rotates to the left - with direction of rotation 1:
- Actuator rotates to the right
- 3. Short-circuit connections 2 and 3: - Actuator runs in opposite direction

## Functions for actuators with specific parameters (Parametrisation with PC-Tool necessary)

Override control and limiting with AC 24 V with relay contacts






1) Caution: This function is only guaranteed if the start point of the operating range is defined as min. 0.5 V.




## **Functions**


## Control open-close








## Operating controls and indicators





Direction of rotation switch

Switch over: Direction of rotation changes

2 Push-button and LED display green

Off: No power supply or malfunction

On: In operation

Press button: Triggers angle of rotation adaptation,

followed by standard mode

3 Push-button and LED display yellow

Off: Standard mode

On: Adaptation or synchronising process active

Press button: No function

4 Gear disengagement button

Press button: Gear disengages, motor stops,

manual override possible

Release button: Gear engages, synchronisation starts,

followed by standard mode

5 Service plug

For connecting parameterisation and service tools

Check power supply connection


2 Off and 3 On Possible wiring error in power supply

## **Service**

#### **Service Tools connection**

The actuator can be parameterised by ZTH EU via the service socket. For an extended parameterisation the PC tool can be connected.


Connection ZTH EU / PC-Tool





# Dimensions [mm]

# Spindle length



# Clamping range

<u>OI</u>	<b>_</b>	<b>♦</b> I
1420	1014	1420

# **Dimensional drawings**

